

**CHOOSING Optigrip<sup>®</sup> / Optifast skis**

- Ski length 5-20 cm over skier's height
- No need for measuring ski stiffness

**CHOOSING NoWax Skin skis**

- Ski stiffness measured according to skier's weight

**Usage of Optigrip and NoWax Skin / Optifast skis**

- Cool down the skis for 5-10 minutes before skiing
- Store the skis indoors to sure the ski base will dry
- Clean the ski base using wax remover if grip is not good enough anymore (see cleaning intructions)
- During snowfall and near zero degrees usage of Optiwax GripCare may avoid freezing

**Cleaning of Optigrip and Optifast skis**

- Base material cleaning is needed if grip or glide propeties are weakened
- Moisten the whole base material with Optigrip GripCleaner or other wax remover
- Rub moistened base powerfully with copper of nylon brush or scouring pad
- Dry up the whole base with a rag or paper.  
Repeat the cleaning procedure if the ski is still dirty.
- Optigrip base becomes most often dirty when skied in wet, old snow conditions

**OPTIGRIP<sup>®</sup>-suksien valinta**

- Suksien sopiva pituus on 5-20 cm yli hiihtäjän pituuden
- Suksien jäykkyyssmittausta ei tarvita

**NoWax Skin suksien valinta**

- Suksen jäykkyys valitaan hiihtäjän painon mukaan

**OPTIGRIP<sup>®</sup> ja NoWax Skin suksien käyttö**

- Jäähdytä suksia ulkona noin 10 min ennen hiihtämistä.
- Säilytä sukset sisätilassa, jotta pohja kuivuu lenkin jälkeen.
- Puhdista pohjat huolellisesti voiteenpoistoaineella, jos suksien pito heikkenee (katso puhdistusohjeet).
- Lumi- ja räntäsateella nollakeleillä Optiwax GripCare-hoitoaineen käyttö pienentää jäätymisriskiä.

**OPTIGRIP<sup>®</sup> ja NoWax Skin suksien puhdistus**

- Puhdistus on tarpeellista, jos suksen pito tai luisto heikkenee olennaisesti.
- Kastele suksen pohja Optiwaxin GripCleanerilla tai muulla voiteenpoistoaineella.
- Hankaa märkää pohjaa voimakkaasti voiteluharjalla tai karhunkielellä.
- Pyyhi pohja kuivaksi paperilla tai rätillä.  
Toista toimenpiteet, jos paperiin / rättiin tarttuu paljon likaa.
- Suksen pohja likaantuu eniten hiihdettäessä vanhalla, märällä lumella.